

LIST EFFECTIVE November 1, 2011

LOM PARTS CUTAWAY

Model LOM

FIG. NO.	PART NO.	DESCRIPTION	4LOM	6LOM	8LOM
1	4LOM-702	4LOM Drive Shaft Assembly-Keyed gear & shaft, woodruff key, retaining ring groove, shaft flat	1		
1	6LOM-702	6LOM Drive Shaft Assembly-Keyed gear & shaft, woodruff key, retaining ring groove, shaft flat		1	
1	8LOM-702	8LOM Drive Shaft Assembly-Keyed gear & shaft, woodruff key, retaining ring groove, shaft flat			1
2	LM-RM2	Mechanical Seal Retainer	1	1	1
3	LM-RR2	Seal Housing Retaining Ring	1	1	1
4	LM-OV2	Viton O'ring	1	1	1
5	L2106-500	1/2" Shaft Type 2106 Mech Seal, Viton	1	1	1
6	LM-WS1	Washer	1	1	1
7	3LOM-1689	Drive Shaft Retaining Ring	1	1	1
9	4LOM-1BEF	1/2" NPT Body W/Ertalyte Bushings	1		
9	6LOM-1BEF	3/4" NPT Body W/Ertalyte Bushings		1	
9	8LOM-1BEF	1" NPT Body W/Ertalyte Bushings			1
10	3LOS-2	Gasket	3	3	3
11	8-186Q-QLF	Cover Screw	6	6	6
12	6LOM-10BEF	Cover W/Ertalyte Bushings	1	1	1
13	4LOS-703	Idler Shaft Assembly - Including Gear, Shaft	1		
13	6LOS-703	Idler Shaft Assembly - Including Gear, Shaft		1	
13	8LOS-703	Idler Shaft Assembly - Including Gear, Shaft			1

